

Rubn®

DESIGN NICLAS HOFLIN

— INSTALLATION INSTRUCTION —

CEILING CUP Ø110 x 65 mm FOR WIRE CABLE

1. Insert cable through tube and loosen screw.
2. Put the wire through the included wire lock as shown **A** and tighten both screws firmly.
3. Connect the cables accordingly by using included connectors **B**.
4. Place the wire loop and the Suspension hook over the ceiling hook (ceiling hook not included). Push cup to the ceiling and tighten the screw.

