

ASSEMBLY GUIDE

BLOOMSBURY WALL

1. Unscrew the 2 track screws to remove the lid
2. Fasten the fixture using 2 screws (not included)
3. Reattach the lid by using the 2 track screws
4. To rotate and set the light source - Loosen the nuts slightly in both ends and tighten again when the arm is set. Then use the thumb-screws to set the light.

