


ASSEMBLY GUIDE

LORD 1 CEILING ADJUSTABLE Ø400



1. Loosen decor **A** to slide back cap **B**.
Attach ceiling plate by using 4 screws (not included).
2. Hang the pendant as shown in step 2.
Connect the cables accordingly using the included connectors **C** and the earth connector.
3. Slide cap **B** against ceiling followed by decor **A** and tighten the decor. To set height use the set screw **D**.

