

Rubn®

DESIGN NICLAS HOFLIN

— INSTALLATION INSTRUCTION —

ANGEL WALL DIRECT 1000

1. Loosen the screw that secures the cover
2. Fasten the fixture using 2 screws (not included)
3. Connect the cables accordingly by using included connectors **A** and the earth connection
4. Reattach the cover using the screw first removed
5. Insert light source

